


- Check all hose clips on the fuel pipes and hoses from the fuel pump to the pressure regulator (fuel pressure side) for tight fit. **Especially the fuel hoses in the distributor line in the engine compartment.** For this purpose, slightly tighten hose clips with a screw driver.

Attention! Do not completely compress hose clips. Gap approx. 2 mm.



Engines 116, 117